



Molex Wiring Connectors

BIG TWIN



Molex Wiring Connectors

VT No.	OEM	Female Connectors	VT No.	OEM	Male Connectors
32-9673	72512-07BK	3 Position Black	32-9682	72511-07BK	3 Position Black
32-9697	72514-07GY	3 Position Grey	32-9694	72513-07GY	3 Position Grey
32-9675	72177-04BK	4 Position Black	32-9685	72175-07BK	4 Position Black
32-9677	72414-07BK	6 Position Black	32-9690	72188-07BK	6 Position Black
32-9678	72479-07BK	8 Position Black	32-9686	72478-07BK	8 Position Black
32-9691	72469-07GY	8 Position Grey	32-9687	72447-07GY	8 Position Grey
32-9679	72487-07BK	12 Position Black	32-9695	72488-07BK	12 Position Black
32-9692	72489-07GY	12 Position Grey	32-9688	72490-07GY	12 Position Grey
32-9680	72166-07BK	16 Position Black	32-9689	72177-07BK	16 Position Black
32-9693	72491-07GY	16 Position Grey	32-9698	72492-07GY	16 Position Grey
32-9681	72500-07BK	20 Position Black			
32-9699	72473-07	Blade Cavity Plugs Pack of 10			
32-9700	72169-07	16-20 Gauge Stamped Pins Pack of 100			
32-9701	72168-07	16-20 Gauge Stamped Sockets Pack of 100			

Handlebar Wiring Extension Kits

VT No.	Description	Wires	Fitment
32-6651	One Size	6 Right/8 Left	2008-up Touring
32-6652	4" Extension	6 Right/8 Left	2007-up FL
32-6656	4" Extension	12 Right/14 Left	2007-up All
32-6660	4" Extension	6 Right/6 Left	1996-2006 FL
32-6664	4" Extension	12 Right/12 Left	1996-2006 All
32-6653	8" Extension	6 Right/8 Left	2007-up FL
32-6657	8" Extension	12 Right/14 Left	2007-up All
32-6661	8" Extension	6 Right/6 Left	1996-2006 FL
32-6665	8" Extension	12 Right/12 Left	1996-2006 All
32-6654	12" Extension	6 Right/8 Left	2007-up Touring
32-6658	12" Extension	12 Right/14 Left	2007-up All
32-6662	12" Extension	6 Right/6 Left	1996-2006 FL
32-6666	12" Extension	12 Right/12 Left	1996-2006 All
32-6655	15" Extension	6 Right/8 Left	2007-up FL
32-6659	15" Extension	12 Right/14 Left	2007-up All
32-6663	15" Extension	6 Right/6 Left	1996-2006 FL
32-6667	15" Extension	12 Right/12 Left	1996-2006 All

