



51-1607



51-1609



51-1601
Installed



51-1601

51-1602



The Touring Torque Linkage System

- No modifications are necessary to install this unit. After the unit is installed it will eliminate the lateral movement while still allowing the Iso mounted factory design of the "floating" drive train to move vertically as designed through connecting the rear of the transmission case to the frame. The kit utilizes an isolation link with a urethane plunger so there is no contact between the frame and engine transmission assembly, therefore reducing vibration.

- 51-1602 includes outer mount bracket in chrome.

VT No.	Finish	Fits
51-1607	Chrome	FLT 1993-2008
51-1609	Black	FLT 1991-2008
51-1601	Black	FLT 1993-2008
51-1602	Chrome	FLT 1993-2008
51-1608	Black	FLT 2009-up

Note: Installation on 1993-2001 models require 27-1235 foot peg spacer set as shown. Purchase 27-1235 separately.



Touring Wide Swingarm Kit

- This new wide swingarm kit come complete with all bolt-on parts necessary to install without modification.
- Kits include new wide rear swingarm with a 1" axle, custom 14 gauge rear OE style fender, saddle bag support kit, drive components, billet primary spacers and all brackets and hardware necessary.
- Allows use of OE stock tail lamp, saddle bags and exhaust.
- Accepts 16" x 5.5" x 17" x 5.5" x 18" x 5.5" rear wheels and most tires up to 200mm wide.
- Requires a 20mm rear belt and pulley.
- Models with 18" rear tire, use OE brake caliper, models with 16" rear tire require a smaller custom brake caliper.
- Installation of a tour pak or backrest will require OEM detachable docking hardware.
- Fits 2002-06 FLHT, FLHR and FLTR touring models.

VT No.	Item
51-1252	Kit
51-1251	Replacement Swing Arm Only



1998-08 Frame for FLHR

- Accepts stock components for these years. Frame shipped in raw finish without swingarm.

VT No. 51-0800



Tri Glide Leveling Kit

- Includes 2 black painted steel plates to raise the rear axle position for installing custom muffler.

VT No. 51-1744