



30-0585



30-0581



### Chrome Crossover Exhaust Header Pipes

• Steel and include heat shields and brackets. 30-0585 includes oxygen sensor.

VT No.	Fits
30-0585	FLT, FLHT, FLHR, FLTR 2007-2008
30-0581	FLT, FLHT, FLHR, FLTR 1995-2006

30-0612



32-1315



### Chrome Crossover Exhaust Header Pipes

• Use original heat shields and clamps.

VT No.	Fits
30-0632	FLT 2010-16
30-0612	FLT 2009
<b>Oxygen Sensor Harness for Above</b>	
32-1315	FLH 2009



**Jims Oxygen Sensor Wrench** for removing and installing the 4 wire heated oxygen sensors. These sensors must be torqued to 14 ft-lbs. Lending to the design of this tool to be used with a 3/8" drive torque wrench.

• Fits 2010-16 FLT.

**VT No. 16-0382**

29-1158



29-1156



30-0426



### Chrome 2 into 1 Exhaust Header

VT No.	Fits
29-1158	FLT, FLHT, FLHS, FLHR 1996-2006
29-1156	FLT 1985-1999
<b>Heat Shields for Above</b>	
30-0426	FLT 1991-2006
30-0306	FLT 1985-1999

29-1198



30-0328



### Chrome True Dual Exhaust Pipes

• Features independent exhaust pipes.

VT No.	Fits
29-1198	FLT 1999-2006
29-1167	FLT 1995-1998
<b>Heat Shields for Above</b>	
30-0328	FLT 1985-2006