



42-0030

Chrome Swingarm Mount Kit

- Includes right and left chrome pivot caps, chrome passenger footboards mounts and chrome passenger footboards with rubber pads for Touring.

VT No.	OEM	Fits
42-0030	47850-88T	1982-89



44-2060

Swingarm Kit

- Includes 2 offset steel bushings and 2 alloy washers.

VT No.	Fits
44-2060	FLT 1980-2008, FL 1980-2008, FLHTC 1980-2008



Nylatron Swingarm Bushing Kit

- Four piece bushing set replaces swingarm bearings and stabilizes swingarm rubber mounts.
- Order pin separately. Order (31-3986 or 31-0443) frame mount bushings separately.

VT No.	Fits
44-0671	FLT 1982-2002, FLHT 1982-2002, FLHR 1995-2002



51-0992

51-0994



Key Tab Detail



51-0992 will retro fit 1982-02 to accept foot pegs and foot board mounts on the right and left side.

*Note: Key tabs to secure rubber bushings.

Chrome Pivot Mount End Caps

- Fit years as noted.

VT No.	Year
51-0992	1982-06
51-0994	2007-08



Swingarm Iso Mount Pin Kit

- Includes pin and outer support bushings with steel side plates for upgrades.

VT No.	Fits
44-2064	1993-02 Touring

Tool Kits



16-0011

DIY Touring Tool Kit

- For 1999-2013 models will fit in a kidney shaped tool box. Includes rider tools and service tools for the rider-mechanic.

VT No.	Fits
16-0011	1999-13
16-0098	2014-up



16-0098