



27-0964



27-0977

### Streamliner Passenger Footboard Kit.

• Includes footboards, rubber pads, mounting hardware. Pads feature three chrome ribs. Set has bolt on installation. Replaces 50378-07B.

Chrome	Black	Item
27-0964	27-0977	Kit



### Black Rear Passenger Footboard Set

• Without rubber inserts.

Fits 1993-up FLT.

VT No. 27-1761



27-1125



27-1126



27-1123



27-1124

### Footboard Set

Chrome	Black	Item
27-1125	27-1126	Block Passenger Rear Footboard Kit
27-1123	27-1124	Ribbed Rear Passenger Kit
27-1549	27-1458	Streamline, FLT 1993-up
27-1456		Streamline, FLT 1993-up



27-1127



27-1128



27-1129



27-1130

### Mount Kit

Chrome	Black	Item
27-1127	27-1128	Reduced Reach Passenger Mount Kit
27-1129	27-1130	Adjustable Passenger Mount Kit