



# Spring Fork Legs



49-0830



23-1207

**Lug Bolt Kit** includes 5 lug bolts and "T" wrench.

**VT No. Lugs**

49-0830 Parkerized

23-1207 Chrome



**Springer Brake Kit.** Early style with finned brake drum. Exact for 1938-39 UL and EL.

**VT No. 22-0740**



**Wheel Cover Set** for glide fork applications on a 16" star hub wheels with brake drum.

**VT No. Fits**

49-0299 1949-66 FL

Front

49-0291 1941-48 FL



37-8675



23-0440



37-8691



37-8919



49-0457



23-0090

**Wheel Lug Bolts** for brake drums. Use tap 16-0807 for  $\frac{3}{8}$ " — 20.

Black	Chrome	OEM	Years	Fits
37-8675	23-0440	43530-35A	1936-72	$\frac{3}{8}$ " — 20
37-8691	—	43530-35A	1936-72	$\frac{3}{8}$ " — 20
—	37-8919	43531-35	Oversize	$\frac{7}{16}$ " — 20
49-0457	—	43531-35	1936-37	$\frac{3}{8}$ " — 20
23-0090	—	43631-35	1936	$\frac{3}{8}$ " — 20

786



49-0313



49-0342

**Inline Fork Legs** fit 1936-52 45" and 1936-48 Big Twin models.

**Rigid Rear Springer Fork Leg**

Black	Chrome	Fits
49-0384	49-0386	1941-45 Big Twin
49-0313	—	1940-57 45 Solo
49-0388	49-0342	1940-57 45 Solo



49-0408

**Front Springer Fork Leg.**

Black	Chrome	Fits
49-0408	49-0409	Spring Fork w/Rods, Big Twin
49-0332	49-0343	45" Front Leg
49-0421*	—	Stud Hole 45"/74" Adapters
7707-4	—	Spring Rods, pair
49-0337	—	45 Servi-Car Rear Leg Inline

\*Note: Allows installation of Big Twin Rockers on 45" fork.



49-1172



49-1312

**Spring Components.**

VT No.	Item
49-1312	Fender Mount Tab
49-1172	Sleeve Set
49-0029	Front Tubes, Raw
49-0051	1" Stem
49-0374	7/8" Stem for 45"



**Brake Tab** fits 1936-57 Spring Fork. Must be welded on.

**VT No. 49-2655**



**Spring Fork Front Brake Anchor Stud Kit**

includes raw steel stud and parkerized adjuster screw. Brake cable anchor stud for front backing plate was used until 1940 on Knucklehead VL, UL, RL, and WL 45". You can also use this stud to make a 1941 and up backing plate into an early style backing plate. Must be peened over or welded into place after installation.

**VT No. 49-1742**