



# Shock Stud Kit



54-0460



54-0448



54-0449



54-0450



54-0451

**Shock Stud Kits** include all pieces for upper and lower positions. Including washers, nuts and lockwashers as necessary. Studs and bolts are zinc plated. Outer nuts and washers are chrome.

VT No.	Years
54-0460	1956-74
54-0448	1979-81

VT No.	Years
54-0449	1982-85
54-0450	1986-90
54-0451	1991-2001



54-0403

**Shock Stud Conversion Stud Kit** updates 1954-74 to late model bushing diameter of 1/2". Kit includes 4 studs, 4 nuts and 8 washers and top covers. Use with VT No. 54-0106 with 1/2" holes.

VT No.	Item
54-0403	Kit
28-0231	Bushings 1/2" Inner Diameter



**Chrome Shock Covers** are a 1950's style top cover. Fit all models of swing arm with stock shocks including 1952-78 Sportster. Some seats may cause interference.

VT No. 54-0154



**Chrome Lower Shock Covers** give the Big Twin look on XL models 1979-up with Showa shocks. Covers install easily without dismantling the shock.

VT No. 54-0206



16-0101

16-0409

16-0100



16-0954

**Shock Tool.**

VT No.	Years
16-0101	1975-78
16-0409	1979-up
16-0100	1952-74
16-0954	1979-up



54-0152



54-0509



54-0153



54-0532



54-0514



54-0124

**Chrome Upper Shock Stud Covers.**

VT No.	Years
54-0152	1965-74
54-0153	1975-78
54-0514	1982-90
54-0509	1991-99
54-0532	1991-2003
54-0124	2004-up



54-0417



2406-10



2405-10

**Chrome or Zinc Plated Rear Shock Studs** with cup washers. Each kit includes two (2) studs and four (4) chrome cup washers. Cup washers and lock nuts may be purchased separately.

**Upper Pair**

Chrome	Zinc	Year
54-0443	54-0414	1956-74
—	54-0417	1975-78
—	54-0455	1991-93 <b>Note:</b> Includes two studs.
—	54-0457	1994-up <b>Note:</b> Two studs only

**Lower Pair**

54-0444	54-0415	1956-74
—	54-0405	1975-78
54-0430	—	1982-91

**Upper-Lower**

2406-10	—	2000-03
2405-10	—	2004-up



**Shock Stud Washer 10 pack.**

VT No.	Type	Finish
54-0418	5/8" Hole Cup	Chrome
54-0419	3/8" Hole Cup	Chrome
54-0420	1/2" Hole Cup	Chrome
54-0421	1/2" Hole x 1" Flat	Chrome
54-0424	5/8" Hole x 1.3" Flat	Zinc
54-0432	3/8" Hole x 1.25" Flat	Zinc

**Nyloc** shock stud nut is 5/8"-18, replaces 7993.

VT No.	Finish	Qty
54-0422	Zinc	10
54-0447	Chrome	4