



FX-FXRS Gauge



Speedometer Heads fit front wheel drive.

VT No.	Type	Model
39-0335	0-140 MPH	1976-83 FX-FXE-FXS 1981-84 FX-FXE-FXS
39-0389	10-120 MPH	1973-83 FX
39-0319	10-150 MPH	1973-83 FX
39-0933	10-120 MPH	1983-94 FXRT



Replacement Electric Tachometer reads 0-8000 RPM. Order lamp separately. Replaces 92042-78A. Fits L1978-84 FX-FXE-FXS. The bezel has an outside diameter of 3.42".
VT No. 39-0318



FX Dash Mount Hardware for 1977-84 gauges on FX-FXE or use speedometer and tachometer brackets 38-0212, 38-0213 to mount gauges in other types of housing.

VT No.	#	Item
28-0619	A	Iso Mount $\frac{5}{16}$
28-0546	B	Iso Mount $\frac{1}{4}$
38-0212	E	Speedometer Bracket
38-0213	F	Tachometer Bracket
39-0120	A-F	Dash Mount Kit



Complete Dash Assembly for 1977-84 FXS includes chrome cover, electric tachometer, speedometer drive, trip cable, indicator lamps, mount hardware and cable.
VT No. 39-0177



FX Gauge Housing fits 1977-84 FXS-FXEF-FXB models. Order rubber gap seal separately.
VT No. Item
39-0117 Chrome Dash
28-0540 Black Gap Seal
37-9063 Dash Cover Plug, chrome



FXS Chrome Dash Screws fit 1977-85 low rider models, four piece sets are available in acorn or allen type screws.

Acorn	Allen	Acorn Allen
8016-4	37-0441	8775-4 8775-4T



Chrome Dash Dress Up Kit includes dash, panel, rubber strip and chrome allen screws. Fits 1977-84 FXE-FXS.
VT No. 39-0912

Re: 2:1 and 2240:60 MPH Speedometer

The Difference is in the RPM.

For example, 2:1 is 60MPH = 2000 RPM and 2240:60 is 60 MPH = 2240 RPM



Replacement Clear Lens replaces fogged, cracked or broken lenses on stock gauges for 1982-83 FXR models. Cut off old lens and plastic-seal new one in place. Sold each.
VT No. 39-0391



Speedometers are the black plastic style. Complete units include brackets. Brackets replacement plastic lens, and fork tube plugs to accept bracket mountings are sold separately.

VT No.	Fits/Item
39-0372	10-150 MPH 1982-83 FXR-FXRS Speedometer
31-3964	Chrome speedometer
39-0391	Lens only, each
33-0133	12V Bulb



Tachometer and Speedometer Covers are formed to fully cover plastic encased instruments on 1982-83 FXR models.
VT No. 42-0350



Speedometer and Tachometer Brackets.

VT No.	Use
39-0143	Single Gauge Housing for 1973-up FX
39-0139	Speedometer & Tachometer Housing for 73-82 FX
39-0140	Cup for Speedometer and Tachometer, 1973-82 FX-FXE
31-3963	Chrome Tachometer Bracket, 1974-84



Reset Cable and Knob replaces 67210-73. Used on all 1973-up FX except 1981-82 FXWG and late 1984-up FXE-80 models.

VT No. 39-0121

High Beam Blue Indicator Lamp with two wire leads. Use on all 1977-up FXS, all FX models, 1980-82, FXE-80 and 1980-up FXWG.

VT No. 39-0122

Red Generator Lamp with two leads fits 1972-74 FX, 1977-85 FXS.

VT No. 33-1962



Chrome Center Tank Panel for the split tanks of 1977-84 FXS-FXSB-FXEF-FXB models.
VT No. 39-0104