



Bushing-Race Pullers




Wheel Race Puller. Replaces service tool 33071, for hubs with tapered races 1973-99. All models.

VT No. Item
16-0425 Puller and Installer
16-0065 Driver



Cross Arm Puller is 1" square bar 4¾" long slotted, with ¾" - 16 bolts, use any size bolt to pull gears and sprockets that have 2 tapped holes, or use with bearing separator 16-0602.

VT No. 16-0499




Wheel Bearing Greaser. Fitting and spigot greases 1973-99 tapered bearings without removing seals, use existing seal spacer or purchase separately.

VT No. Item
16-0803 Tool
44-0303 Collar

4-Speed Transmission Tools



Big Trans Stud Installer Tool for 1936-86 4 and 5-Speed Softail.
VT No. 16-0719



Mainshaft/Drive Bearing Press Tools.

VT No.	OEM	Fits	Press
16-0105	33428A	1979-84 BT 4-speed	Shaft
16-0036	34734	1979-90 BT 5-speed	Seal
16-0028	34810	1984-90 XL	Drive
16-0057	34733	1977-84 Big Twin	Countershaft
16-1755	35820-86	1986-90 XL	Countershaft
16-0117	34735	1936-38	Gear



2000-up Wheel Bearing Puller and Installer Tools. Use on all 2000-up Twins. 16-0561 includes arbor to pull ¾", 1" and 25mm sealed bearings.

VT No.	Item	Fits
16-0561	Puller and Installer	2000-up (18 pc)
16-0732	Puller and Installer	2000-06
16-0558	Puller and Installer	2000-06
16-1370*	Puller	2007-up
16-1371*	Installer	2007-up
16-1641	Washer Puller Tool	

*Note: Requires 16-0732 tool also for use.



Mainshaft Starter Clutch Gear Puller for 1936-84 4 Speed model.
VT No. Brand
16-0712 V-Twin
16-0740 Jims



Mainshaft Ball Bearing Lock Nut Wrench replaces 94635-41A. Fits 1940-up Big Twin models. Handle is not included.
VT No. 16-0116



Adjustable Reamers use to fit I.D. on new bushings.
VT No. Years Fits
16-1798 1941-85 BT Main Drive Gear
16-1799 1936-84 BT-XL Kicker Shaft
16-0878 1936-57 BT Brake Cross Shaft
16-1801 1936-84 BT Clutch Release Shaft



Wheel Bearing Wrench removes the slotted lock nut on spoke wheels. Sportster and 1967-72 Big Twins. Replaces 94630-67.

VT No. Type
16-0155 V-Twin with Handle
16-0657 Jims with ½" Drive



Bushing Puller Tool will extract bushings in blind holes of cam covers.
VT No. 16-0231





Jims Rear Wheel Compensator Bearing Remove/Installer Tool used to remove or install the ball bearing in rear pulley on all 2008-up FLT models. Tool will center and guide the bearing for proper installation.
VT No. 16-0315



Big Twin Mainshaft Seal Remove and Installer replaces 95660-42. Use to install and remove main seal. This tool will push seal in as flat and straight as possible to .050 below housing for a no leak fit.

VT No.	Years	Speed
16-1803	1936-76	4
Additional Drivers for Above		
16-0702	1977-86	4, (2.4 O.D.)
16-0701	1980-84	5
16-0700	1985-up	5




Shifter Fork Gauge is used to set and align shifter forks on Big Twin 4-speed models.

VT No.	Jims	#	Years
16-0121	16-0641	A	1939-78
16-0120	16-0642	B	1979-84

Countershaft Sprocket Nut Tool



4-Speed Transmission Arbor replaces clutch hub nut to allow test rotation with ½" drill.
VT No. 16-1274



Countershaft Sprocket Lock Nut Wrench features an extra long two piece design inner collar which will retain wrench to nut. Fits 1936-2005 Big Twins, 1½" hex, 4 and 5 speed models.

VT No.	OEM	Brand
16-0821	94660-37A	V-Twin
16-0054	99660-37A	V-Twin
16-1505	Collar	V-Twin
16-0757	94660-37A	Jims ½" Drive



Big Twin Countershaft Sprocket Nut Tool is a factory style tool.

VT No.	Models	Use
16-0114	1937-84	4-Speed Big Twin 4th Gear Sprocket Nut
16-0901	All	Handle for above
16-0823	1941-73	45
49-0366	1936-40	Big Twin